

## Tonnage Interface

As an option, the OnTrack system can be set up with a link to a tonnage monitor in order to:

- (1) Provide setup information to tonnage system
- (2) Provide the tonnage monitor with current state and count information
- (3) Receive tonnage alarms from the tonnage monitor

If the "Production Messaging" option is used in the plant, the tonnage alarms will be directed to key personnel.

